

## GRAN DEZ 2008

## **Technical Data Sheet**











SYMBOL	pН
SP-25	1

Acidic product, designed for cleaning and disinfecting acid-proof surfaces in the kitchen, gastronomy and food industry.

Recommended for disinfecting machines and devices from stainless steel and non-ferrous metals that have contact with food. Does not contain toxic substances.

Removes mineral sediments of limy origin, rust dripstone and burdensome inorganic impurities. Odourless.

Works according to the PN-EN 1276, PN-EN 1650 and PN-EN 13697 norm.

Permission for trading biocidal product 3437/08.

Product has Certificate of the National Institute of Hygiene – PZH (HZ/147/2013).

### **APPLICATION:**

- all surfaces made from stainless steel, chrome and nickel that have contact with food.
- equipment used in meat processing establishments
- sanitary surfaces

### **COMPOSITION:**

- < 5% anionic surfactants</li>- < 5-15% non-ionic surfactants</li>

- 100 g/kg didecyl dimethyl ammonium chloride (DDAC)

- < 40% phosphoric acid (75%)

- auxiliary substances not classified as dangerous

tel. +48 91 311 97 77 fax. +48 91 311 97 79

E-mail: info@tenzi.pl, www.tenzi.pl



### GRAN DEZ 2008

## **Technical Data Sheet**

### **USAGE:**

Before using, read product's safety data sheet.

Make a working solution just before using it.

Spread it on the surface at temperature of 20°C:

- bacteria: 2% (200 ml / 10 l of water), 5 minutes.

- fungi: 5% (500 ml / 10 l of water), 15 minutes.

After disinfection, wash down the surface with large amount of drinking water. Ventilate the room for at least 5 minutes.

Warning: Use strictly according to the product's label.

### **DANGER:**



- Causes severe skin burns and eye damage.
- Causes serious eye damage.
- Very toxic to aquatic life.
- Wear protective gloves/protective clothing/eye protection/face protection.
- IF SWALLOWED: Rinse mouth. Do NOT induce vomiting.
- IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water [or shower].
- IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- Immediately call a POISON CENTER/doctor
- Store locked up.

### **SELL-BY DATE:**

12 months from the production date.

Production date/series and expiration date are stated on the packaging.

tel. +48 91 311 97 77 fax. +48 91 311 97 79

E-mail: info@tenzi.pl, www.tenzi.pl



## **GRAN DEZ 2008**

# **Technical Data Sheet**

#### ADDITIONAL INFORMATION:

Additional information can be found in safety data sheet.

Contaminated containers should be completely emptied. Several times rinse the container promptly after emptying. Empty container can be stored in containers for collection of plastic packaging, or can be delivered to specialized company for recycling.

Disposal should be in accordance with the national/international regulations

tel. +48 91 311 97 77 fax. +48 91 311 97 79

E-mail: info@tenzi.pl, www.tenzi.pl